


Three-phase



NEW!

Ia/I_n = ratio between start-up current and maximum current. ** Slot. °Running capacitor / *Additional capacitor only for start-up

Several sizes are available with different mounting bolt patterns. Please contact sales office at Italvibras.